



## Numark Pro CD Player

- Selectable  $\pm 8/16\%$  pitch ranges
- Large green Start/Pause button!
- Power switch protector, all-rubber buttons

## Aeromix 1+1EU Mixer [ARMX1+1]

- Upgraded Stereo Voice over Music Mixer
- Only 2 Volume Controls to get right!
- Screwdriver adjustable Treble and Bass Controls for Voice and Music
- Now with a "Walk up and plug in Socket" for MP3 players etc. on the front panel
- Master Volume Control located on the back panel "set & forget"

## Aeromix 2+2EU Mixer [ARMX2+2]

- New Improved! Stereo Voice over Music Mixer
- Only 4 front panel Volume Controls to balance!
- Smaller separate Treble and Bass Controls for Voice and Music EQ-ing
- 2 Pairs of Balanced TRS Jack Sockets @ 1V & 1.5V to match all power amps
- Now with a "Walk up and plug in Socket" for MP3 players etc. On the front panel
- Master Volume Control located on the back panel "set & forget"
- Music Mute Relay circuit

WWW.FITNESSAUDIO.NET

### Fitness Audio Denmark

Knud Danielsen A/S

Tel: +45 4913 0120

Fax: +45 4913 0125

Mobil: +45 4056 8104

e-mail: info.dk@fitnessaudio.net

### Fitness Audio Sweden

MUG Audio AB

Tel: +46 31 130 990

Fax: +46 31 711 3730

Mobil: +46 708 664 823

e-mail: info.se@fitnessaudio.net

### Fitness Audio Norway

Watt Engros A/S

Tel: +47 6791 1050

Fax: +47 6791 1051

Mobil: +47 9202 4568

e-mail: info.no@fitnessaudio.net

### Fitness Audio Finland

Knud Danielsen A/S

Tel: +45 4913 0120

Fax: +45 4913 0125

Mobil: +45 4056 8104

e-mail: info.fi@fitnessaudio.net