

## Aeromic Pouchbelt [AM10PB]

Aeromic Standard Black Pouchbelts (straight pocket) suits almost all brands of transmitters we know about.



WWW.FITNESSAUDIO.NET

## Zipster Pouchbelt [AMPBDLZIP]

Aeromic Zipster Pouchbelts in Black, Red or Blue. A double zipper secures the transmitter and gives easy access to Power on/off switches positioned on the front face (TOA) or side edge (Sennheiser) of today's body pack transmitters. The Zipster enables you to easily put the transmitter into the pocket upside-down so as to seal off the top of the pouch if that's what you believe will solve your particular sweat problem.



### Fitness Audio Denmark

Knud Danielsen A/S

Tel: +45 4913 0120

Fax: +45 4913 0125

Mobil: +45 4056 8104

e-mail: [info.dk@fitnessaudio.net](mailto:info.dk@fitnessaudio.net)

### Fitness Audio Sweden

MUG Audio AB

Tel: +46 31 130 990

Fax: +46 31 711 3730

Mobil: +46 708 664 823

e-mail: [info.se@fitnessaudio.net](mailto:info.se@fitnessaudio.net)

### Fitness Audio Norway

Watt Engros A/S

Tel: +47 6791 1050

Fax: +47 6791 1051

Mobil: +47 9202 4568

e-mail: [info.no@fitnessaudio.net](mailto:info.no@fitnessaudio.net)

### Fitness Audio Finland

Knud Danielsen A/S

Tel: +45 4913 0120

Fax: +45 4913 0125

Mobil: +45 4056 8104

e-mail: [info.fi@fitnessaudio.net](mailto:info.fi@fitnessaudio.net)